




TERMINAL USER GUIDE

Instalment (IPP) | Visa & Instalment Services


GHL MAH DA

Terminal Model: Nexgo N86




Instalment | Visa IPP


Terminal Model: Nexgo N86




STEP 1 Press on **Visa IPP**




STEP 2 Key in instalment amount & press **OK**



STEP 3 **Insert** or **Tap** customer's card




STEP 4 Select preferred Instalment tenure by scroll up / down the screen




STEP 5 Press **Confirm**

Instalment | Visa IPP


Terminal Model: Nexgo N86




STEP 6 Customer enters card PIN and press **Confirm**




STEP 7 Please wait while the transaction is in process



STEP 8 Merchant receipt is printed out




STEP 9 Press **Yes** for customer receipt




STEP 10 Customer receipt is printed out

Instalment | Instalment Services IPP


Terminal Model: Nexgo N86




STEP 1
Press on **Instalment Services**




STEP 2
Select preferred Instalment tenure



STEP 3
Key in instalment amount & press **OK**




STEP 4
Insert or **Tap** customer's card



STEP 5
Press **Confirm**

Instalment | Instalment Services IPP


Terminal Model: Nexgo N86



STEP 6 Customer enters card PIN and press **Confirm**



STEP 7 Merchant receipt is printed out



STEP 8 Press **Yes** for customer receipt



STEP 9 Customer receipt is printed out