




### PRE-AUTH




1. Press <ENTER> key to access main menu




5. Key in 6 digit PIN and press <ENTER> key




2. Select 5 for PRE-AUTH and press <ENTER>




6. Sending to Host for processing




3. Key in amount and press <ENTER>



7. Transaction approved and merchant's receipt printed out




4. Insert Card / Manual Entry / Scan QR




8. Press YES to print customer receipt


### PRE-AUTH COMP




1. Press <ENTER> key to access main menu




5. Key in 6 digit PIN and press <ENTER> key




2. Select 6 for PRE-AUTH COMP and press <ENTER>




6. Sending to Host for processing




3. Key in amount and press <ENTER>



7. Transaction approved and merchant's receipt printed out




4. Refer to sale slip, key in Trace# and press <ENTER>




8. Press YES to print customer receipt


### REFUND




1. Press <ENTER> key to access main menu




5. Key in 6 digit PIN and press <ENTER> key




2. Select 4 for REFUND and press <ENTER>




6. Sending to Host for processing




3. Key in amount and press <ENTER>



7. Transaction approved and merchant's receipt printed out



4. Tap / Insert Card / Scan QR



8. Press YES to print customer receipt