



REPRINT LAST RCPT




1. Press **<ENTER>** key to access main menu



2. Select **8** for **REPRINT** and press **<ENTER>**




3. Select **1** for **LAST RECEIPT** and press **<ENTER>**




4. Press **YES** to print customer receipt


REPRINT ANY RCPT




1. Press **<ENTER>** key to access main menu



2. Select **8** for **REPRINT** and press **<ENTER>**




3. Select **2** for **ANY RECEIPT** and press **<ENTER>**



4. Refer to sale slip, key in Trace# and press **<ENTER>**


REPRINT LAST SETTLE




1. Press **<ENTER>** key to access main menu



2. Select **8** for **REPRINT** and press **<ENTER>**




3. Select **3** for **LAST SETTLE REPORT** and press **<ENTER>**




4. Press **<ENTER>** to proceed

REPORT (DETAIL / SUMMARY)




1. Press **<ENTER>** key to access main menu




2. Select **9** for **REPORT** and press **<ENTER>**




3. Select **1** for **DETAIL REPORT** and press **<ENTER>**



8. Press **YES** to print **DETAIL REPORT**




1. Press **<ENTER>** key to access main menu



2. Select **9** for **REPORT** and press **<ENTER>**



3. Select **2** for **SUMMARY REPORT** and press **<ENTER>**



8. Press **YES** to print **SUMMARY REPORT**