

## TERMINAL USER GUIDE


**MAYBANK PAYHERE DIRECT** 


**Terminal Model: Android N5** 

Property of GHL Systems Berhad




## Void **Terminal Model: Android N5**





**STEP**  $\square$ 

Key in Void password (Last 4 digits of MID) and press  $\sqrt{}$ 






Select host to proceed void


 $\square$ 







STEP

Once void details confirmed, press **OK** to proceed



## Void **Terminal Model: Android N5**





printed out

Terminal User Guide

